MIRRORSTONE
LIGHTING SPECIALIST

4 zone RGB+CCT remote

Model No.:MS-EZI-C5

Product Feature

- 2.4GHz wireless transmitting technology , fast transmitting,
  stable signal and anti-interference
- Control multi devices at the same time
- Dim color, brightness and mode
- Change color and speed of dynamic mode
- Working with multi controllers (control distance 30m)
- simple magnetic installation
- Control lighting scene freely , for commerical and home lighting scene

Product Parameter

Product Name：	4 zone RGB+CCT remote	Working temperature：	-10~40℃
Model No.::	C5	EMC standard(EMC) :	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-3 V2.3.2
Working voltage:	3V(AAA*2PCS)		
Standby consumption:	15μA	Security Standard（LVD）:	EN 61347-2-11：2001+A1: 2019 EN 61347-1: 2015+A1:2021 EN 62493:2015+A1:2022
Transmission：	6dBm		
Protocol：	2.4GHz RF	Radio equipment（RED）:	ETSI EN 300 400 V2.2.1
Modulation：	GFSK	Certification：	CE、EMC、LVD、RED
Control Distance:	30M		

Remote	Remote Holder

140mm
45mm
18mm

86.5mm
49mm
7mm

Function

Indicator —
RGB slider

Brightness slider

White
Master ON
Speed- CCT- Saturation+
Master OFF
Speed+ CCT+ Saturation-
Mode

" I "Group ON
(Link/Unlink)
" O " Group OFF

MiBOXER
Model No.: C6

Function

White: For white color

Dynamic Mode: Press continuously to change different mode

RGB Ring:

Change RGB color

Group ON (Link/Unlink): For different zones

" I " ON(Link/Unlink) "O" OFF

Brightness slider:

Dim brightness

Multi Function:

Speed-/ CCT-/ Saturation+

(S−/ ◉)

For dynamic mode, speed-

For white mode, CCT-

For RGB mode, saturation+

Multi Function:

Speed+/ CCT+/ Saturation-

(S+/ ◉)

For dynamic mode, speed+

For white mode, CCT+

For RGB mode, saturation-

Link/Unlink

Link	controller must link with remote before using it

① turn off light 10 seconds and turn on again

② short press "ON" 3 times within 3 seconds

③ link is done once light flashes 3 times slowlyyy

⚠ Link is failed if light doesn't flash, please repeat above steps
（Attention: can not link again if remote already finished linking）

Unlink

① turn off light 10 seconds and turn on again

② short press "ON" 5 times within 3 seconds

③ link is done once light flashes 10 times quickly

⚠ Unlink is faild if light doesn't flash, please repeat above steps
（Attention: no need to unlink if the light never be linked）

Installation

Remove the sticker on the holder

Stick the holder on the wall and put remote on the holder

Attention:

1. Don't use it in humidity or high temperature area, please take out battery if don't use it frequently and keep it in dry or static electricity area

2. Don't use it near metal or strong magnetic area, it will affect signal and lost distance.